

ADJUSTMENT GUIDE FOR PULL TYPE CLUTCHES
(14" Single Plate, 14" Twin Plate, 15.5" Twin Plate)

- 1 With the inspection cover removed, a hammer and a screw driver is used to unlock the locking nut.
- 2 The release travel clearance is set by turning the slotted adjustment nut (nearest the release bearing) until the correct gap of 1/2" is achieved.
- 3 On completing the adjusting procedure the release sleeve lock-nut is securely locked back into the position against the release lever spider.

